

Relay™ RXS12

Pilot's Guide

Manuel de pilotage

Pilotenhandbuch

Pilotenhandboek

Manual del Piloto

取扱説明書



40-00-0235

Electroponic Limited Edition available @ www.line6.com/manuals

Rev B



You should read these Important Safety Instructions. Keep these instructions in a safe place.

Before using your Relay™ RXS12 carefully read the applicable items of these operating instructions and the safety suggestions.

1. Obey all warnings in the Relay™ RXS12 manual.
2. Only use non-rechargeable alkaline batteries in the transmitter.
3. Do not perform service operations beyond those described in the Relay™ RXS12. Service is required when the apparatus has been damaged in any way, such as:
 - liquid has been spilled or objects have fallen into the apparatus
 - the unit has been exposed to rain or moisture
 - the unit does not operate normally or changes in performance in a significant way
 - the unit is dropped or the enclosure is damaged.
4. Do not place near heat sources, such as radiators, heat registers, or appliances which produce heat.
5. Guard against objects or liquids entering the device. Do not use or place unit near water.
6. Do not step on cords. Do not place items on top of cords so that they are pinched or leaned on. Pay particular attention to the cord at the plug end and the point where it connects to the device.
7. Always switch transmitter off when not in use for extended periods of time for extended battery life.
8. Clean only with a damp cloth.
9. Only use attachments/accessories specified by the manufacturer.
10. Prolonged listening at high volume levels may cause irreparable hearing loss and/or damage. Always be sure to practice "safe listening."

CERTIFICATION


THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE D OPERATION.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



This Class B digital apparatus complies with Canadian ICES-003. This Category II radiocommunication device complies with Industry Canada Standard RSS-310.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. Ce dispositif de radiocommunication de catégorie II respecte la norme CNR-310 d'Industrie Canada.





Receiver Hook Up

Line 6 DC-1g power supply



To turn on the receiver, plug the DC-1g power supply into the receiver's 9V DC input jack.





To Tuner or Aux Input

Direct To Amp

OR

To FX / Then To Amp




Receiver LED's

Audio LED:

- Green = Audio signal is present


Power LED:

- Blue = Power On



Transmitter Signal Level LED Indicators:

- 3 Green = Data excellent, interference low
- 2 Green = Data OK, may have some interference
- 1 Green = Data minimal, may have significant interference
- No LED = No data, no interference
- 1 Red = No data, some interference
- 2 Red = No data, more interference
- 3 Red = No data, high interference



Transmitter Battery Level LED Indicators


- 3 Green = Full charge
- 2 Green = Excellent charge
- 1 Green = OK charge
- 1 Red = Low charge
- Flashing Red = Very low charge

Changing Channels


Align the RXS12 Receiver's channel to the channel selected on the TBP12 Transmitter.

See TBP12 manual for channel setup instructions.

TBP12 Transmitter




RXS12 Receiver



Cable Tone

Adjust Cable Tone to desired effect:

Longer length value =
Darker Tone



Register and Get Free Stuff

Included with the Relay™ RXS12 is a handy, postage-paid card for you to send back to us to register your purchase. It is very important you either fill that registration card out right now and send it to us in the mail, or register online at www.line6.com/register. That gets you all set up for warranty service in case you should ever have a warranty issue with your product. Registering also qualifies you for contests, special offers and more.

www.line6.com/manuals

Select Relay™ Wireless Advanced Guide in our online manual archive to download our online companion manual describing details of the features in your Relay™ RXS12.